

Requirements

Printer Drivers

The Xerox printer drivers require:

- A maximum of 32 MB of available hard disk space per CentreWare Windows printer driver.
- Internet Explorer 5.5 or higher installed on the workstation for Windows NT, 2000, XP, or Server 2003 drivers.

Xerox Printer Driver Installation Utility

The Xerox Printer Driver Installation Utility and Admin Config Wizard require:

- Administrator privileges in Windows NT / 2000 / XP / Server 2003.
- Internet Explorer 5.5 or higher.
- Microsoft TCP/IP Printing installed and running to connect Peer To Peer in a Windows NT environment.
- Service Pack 2 installed on Windows XP systems.
- Service Pack 4 installed on Windows 2000 systems.
- Service Pack 6 installed on Windows NT systems.

Installing Printer Drivers on Windows Networks

In Windows environments, you can install a Xerox printer driver by using a direct installation, a custom installation, or a Point and Print installation.

Direct Installation

Use the Xerox Printer Driver Installation utility to install Xerox printer drivers for your network printers quickly and easily. If you have the *CentreWare Print and Fax Services CD* or know the network location where the contents of the CD have been saved, you need only run the installer once per Xerox system to install the drivers for multiple page description languages (PDLs) directly onto a PC or print server.

NOTE: You can use the Add Printer Wizard to install Xerox printer drivers, but you must install each driver separately.

Custom Installation

System administrators can use the Admin Config Wizard to pre-configure the driver installation. Use this wizard to control settings such as printer detection method, default printer assignment, and network printer sharing. Set multiple installation configurations to distribute and apply the settings to individuals or groups, as appropriate.

Copy the contents of the *CentreWare Print and Fax Services CD* to your network. Then start the Admin Configuration Wizard to set up a configuration file. (See *Customizing the Installation* on page 2-8 to perform a custom installation.)

Point and Print Installation

Copy the contents of the *CentreWare Print and Fax Services CD* to your network. Install the drivers locally and modify the device settings and document settings (see *Preconfiguring Default Driver Settings* on page 2-17). Then copy the new configurations to the server for enterprise use (see *Point and Print Installations* on page 2-16).

NOTE: It is possible to upgrade a Windows driver without uninstalling the previous version. However, the impact of such an upgrade on system performance can be unpredictable. The most reliable way to upgrade is to uninstall the old drivers and perform a clean installation of the new ones. For information on uninstalling drivers, see *Uninstalling Windows Printer Drivers* on page 2-25.